

Cleaning machines in use




B 291-1



Roll to the location of operation



Maintain control



Only disconnect at the plug



Do not use damaged lines.
Report damage.